

Description

With Delta VFRU-HERV-02BS switch for ERVs, you can activate the boost mode and select the air flow percentage.

Features


- Power indicator
- Boost mode control

Power Indicator



The indicator turns green when the ERV is running and turns off when the ERV is not operating

Boost Mode Control

The VFRU-HERV-02BS offers Boost Mode that ensures optimal ventilation in any situation. With Boost mode activated, the supply and exhaust air are maintained at highest air flow, providing high-performance air exchange. Boost mode features 20,40- and 60-minutes countdown timer, allowing for targeted ventilation without unnecessary energy consumption.



Dimension



Notes:

1. VFRU-HERV-01BS and VFRU-HERV-02BS cannot be used in the same ERV control loop.

Model	Quantity	Comments	Project:
			Location:
			Architect:
			Engineer:
			Contractor:
			Submitted by:
			Date: